





G


C

INSTALLATION INSTRUCTIONS

B

LIST OF CONTENTS:

- A. Aluminum Drive Stand
- B. Large Pulley
- **C.** Control Box
- **D.** Motor Bracket
- E. Wrapping Motor Pulley
- F. Drying Motor Pulley
- G. Indexed 3-Jaw Chuck
- H. Voltage Readout
- I. Speed Control Knob
- J. Three Position Switch
- K. Wrapping Motor
- L. Drying Motor
- M. Foot Pedal
- N. Toothed Belt
- O. Silicone Belt
- P. Mounting Hardware
- (4x Bolts, 4x Lock Washers, 4x Flat Washers, 4x Nuts)
- Q. Mounting Tools (Hex Screwdriver & Flat Wrench)
- R. Concave Teeth (Pre-Installed)





1. To mount the RBS PRO G2 Wrapper to an aluminum base (not included), you will need the Mounting Hardware (P) and the Mounting Tools (Q). Align the pre-drilled holes of the Aluminum Drive Stand (A) to the pre-drilled holes of the aluminum base.



2. Install the mounting hardware starting on the side with the control box (C). Each bolt should have a lock washer, flat washer, and lock nut. Remove the lock nut, then install the bolt (with lock washer and flat washer) from the bottom side of the aluminum track. Once the bolt is pushed through the pre-drilled holes, apply the lock nut to the bolt and hand tighten. Use the included mounting tools to properly secure the hardware. Repeat this process on the opposite side of the drive stand.



FEATURES & USES



DIGITAL VOLTAGE READOUT

The digital readout will display a number in volts. At rest, this number will typically be around 120 volts (+/- 5). The Power Knob is used to control speed. Once you find a speed you prefer, you can reference the voltage number for repeatability.



ADJUSTABLE MOTOR PLATE & PULLEYS

Allows the builder to fine tune the alignment of the motor plate and pulleys. The plate and pulleys are preset to the optimal position for proper belt tension. Only adjust if necessary.



INDEXED CHUCK

With 15 degree increments, the indexed chuck is helpful for spiral wrapped rods or designing a decorative thread wrap. Tighten by turning clockwise or loosen by turning counter-clockwise.



TWO DRIVE BELTS

Toothed belt is recommended for the wrapping motor and the silicone belt is recommended for the drying motor.



CONCAVE & CONVEX TEETH

Interchangeable teeth allow the chuck to securely hold a wide range of rod blanks and mandrels.



THREE POSITION SWITCH

With the built-in switch, you can easily change between wrap, dry, or off.

PULLEY SPEED CHARTS

WRAPPING MOTOR

| | Pulley | Ratio | Max RPM | |
|---------------------|---------------------|--------|---------|--|
| Large WP- Small HSP | | 3.43:1 | 1892 | |
| | Small WP- Large HSP | 5.54:1 | 1173 | |

DRYING MOTOR

| Pulley | Ratio | Max RPM |
|---------------------|--------|---------|
| Large DP- Small HSP | 3.43:1 | 12 |
| Small DP- Large HSP | 5.54:1 | 8 |





Wrapping

Pulley

(WP)



(DP)



Small





Large Drying Pulley

RECOMMENDED CONFIGURATIONS

| Technique | Pulleys | Belt | Digital Readout | Estimated RPM |
|-------------------------------------|----------------------|---------------------|---------------------|-------------------|
| Wrapping Guides | Small WP - Large HSP | Toothed or Silicone | 45 volts - 50 volts | 100 rpm - 200 rpm |
| Turning Grips (cork, EVA, etc.) | Large WP - Small HSP | Toothed | 60 volts - 70 volts | 625 rpm - 850 rpm |
| Applying Thread Finish (high speed) | Small WP - Large HSP | Toothed or Silicone | 45 volts - 50 volts | 100 rpm - 200 rpm |
| Applying Thread Finish (low speed) | Large DP - Small HSP | Silicone | n/a | 12 rpm |
| Drying Thread Finish | Small DP - Large HSP | Silicone | n/a | 8 rpm |





GENERAL SAFETY WARNINGS

Read all safety warnings and instructions before use. Failure to heed warnings could result in Electric Shock, Fire, Damage to Components or Injury.

- 1. Keep work area clean and well lit.
- Do NOT operate in water, near wet conditions, or in the presence of flammable liquids, gasses, or particulates. Indoors only.
- 3. Do NOT Pull on, damage, or modify core or plug for motor of foot pedal. Keep cords away from heat, sharp edges, or moving parts.
- 4. Avoid excessive or prolonged use of the foot pedal, especially on carpeted surfaces.
- 5. Eye protection should be worn at all times. When sanding, respiratory protection is recommended.
- 6. Keep loose clothing or long hair away from the RBS-PRO G2 during operaton.
- 7. Keep out of reach of children.



CRBPRODUCTS.COM